
Hik Vision Firmware update using iVMS

21 January 2021 10:17

- 1. Download your required firmware from the Hik Vision Portal http://www.hikvisioneurope.com/uk/portal/

 2. In the IVMS-4200 we need a device management tab.
- 3. Locate your device and now go into device remote configuration, and for that press the cog button on the right of the device' line, and from there go to System → System Maintenance, and here you've got remote upgrade item.



3. Now let's press dots icon and locate the downloaded firmware file $\,$ digicap.dav . From there just press upgrade, you will see this prompt, saying that after the update device is going to reboot and that's fine, OK. After this process is done – you can continue working with your NVR or DVR just like you did before, but running a new firmware. That's it.

