How to Enable Motion Detection - Push Video Alerts - on a AVTECH System

1. Make sure **MOTION DETECTION** is enabled on the required camera's



3. In the AVTECH menu select - SCENARIO



2.

4.


6.

8.

5. Click Plus icon at the bottom of the screen to create a new scenario



7. Choose the following template – ONE OF (EVENT) TO DO (ACTION)




9. Give the Rule a Name and then click Event option



11. Click PLUS and select Motion and Alarm–Motion–Select required Channels – click OK




13. Click PLUS and select Notification-Push to video to see playback -click OK



15. You will now a have created the below scenario, make sure it's enabled.



17. Check the following scenario settings are enable or disabled



18.

Before configuring Push Video, make sure:

- 1. The system is set up as described in "2. CONNECTION" at page 3.
- 2. This recorder is connected to Internet.
- 3. You've installed the app, EagleEyes, on your iOS or Android mobile devices.

A2.3 Enable Push Video

A2.3.1 From iOS Mobile Device

Step1: In the iPhone / iPad main menu, select **Settings** → **Notifications**. Select **EagleEyes**, and make sure the notification is set to on.

