

Step4: (Optional) If **USB DEVICE** is chosen, specify the directory in **STORAGE** if needed.

















































Step5: Choose **BACKUP** to start. The backup video will be in the AVI format.

Note: When the video compression format is H.265, please use the video player which supports H.265 to play the video footage.

6.5.2 SCHEDULE

This function is used to schedule video backup regularly, uploading security footages to a FTP site (remotely) or saving to an USB device connected to this device (locally).

You can configure up to 7 schedules and use one of them as your backup preference.

BACKUP																																	
SOURCE	DESTINATION																																
PROFILE	TARGET																																
ACTIVE	STORAGE																																
RESOLUTION	FTP PROFILE																																
EXECUTION PERIOD	FTP PATH																																
EXECUTION TIME																																	
RANGE																																	
<div> <div> <div>SCHEDULE1</div> <div>▼</div> </div> <div>ON</div> <div>RECORD STREAM</div> <div>▼</div> <div>DAILY</div> <div>▼</div> <div>MON</div> <div>01</div> <div>MON</div> <div>08</div> <div>:</div> <div>00</div> <div>~</div> <div>FRI</div> <div>19</div> <div>:</div> <div>00</div> </div> <div> <div>FTP</div> <div>▼</div> <div>Profile1</div> <div>▼</div> <div>/VIDEO</div> </div>																																	
CHANNEL <input type="checkbox"/> ALL																																	
<table border="1"> <tbody> <tr> <td>CH1</td> <td>CH2</td> <td>CH3</td> <td>CH4</td> </tr> <tr> <td> <input checked="" type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input checked="" type="checkbox"/></td> <td> <input type="checkbox"/></td> </tr> <tr> <td>CH5</td> <td>CH6</td> <td>CH7</td> <td>CH8</td> </tr> <tr> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> </tr> <tr> <td>CH9</td> <td>CH10</td> <td>CH11</td> <td>CH12</td> </tr> <tr> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> </tr> <tr> <td>CH13</td> <td>CH14</td> <td>CH15</td> <td>CH16</td> </tr> <tr> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> <td> <input type="checkbox"/></td> </tr> </tbody> </table>		CH1	CH2	CH3	CH4	 <input checked="" type="checkbox"/>	 <input type="checkbox"/>	 <input checked="" type="checkbox"/>	 <input type="checkbox"/>	CH5	CH6	CH7	CH8	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	CH9	CH10	CH11	CH12	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	CH13	CH14	CH15	CH16	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>
CH1	CH2	CH3	CH4																														
 <input checked="" type="checkbox"/>	 <input type="checkbox"/>	 <input checked="" type="checkbox"/>	 <input type="checkbox"/>																														
CH5	CH6	CH7	CH8																														
 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>																														
CH9	CH10	CH11	CH12																														
 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>																														
CH13	CH14	CH15	CH16																														
 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>	 <input type="checkbox"/>																														
<div>APPLY</div>																																	

Step1: In **SOURCE**, choose the profile you'd like to save all the settings configured in **SOURCE**.

Choose the video resolution (**SUBSTREAM** / **RECORD STREAM**), how often and when you'd like the backup to execute (**EXECUTION PERIOD** / **EXECUTION TIME**), and the time which includes the recordings you want (**RANGE**).

Step2: In **CHANNEL**, choose the channel(s) you want.

Step3: In **DESTINATION**, choose where you want to save the data, in a USB flash drive (**USB DEVICE**) or on FTP (**FTP**).

Step4: (Optional) If **FTP** is chosen in **DESTINATION**, go to **STORAGE**, and choose the profile you'd like to save the storage path configured in **FTP PATH**.

Then, specify the directory where you'd like the recordings to be uploaded in **FTP PATH**.

Step5: Click **APPLY** to confirm.

6.5.3 REGULAR REPORT

This function is used to send event reports to the specified E-mail address. Users could configure up to 5 profiles to receive different reports about specific channels at different time.

Note: This function is available only when a hard disk is installed, and the recorder is connected to Internet.

You can configure up to 7 profiles and use one of them as your backup preference.





BACKUP																																		
SOURCE <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 60%;"> PROFILE ACTIVE EXECUTION PERIOD EXECUTION DAY OF WEEK EXECUTION HOUR </div> <div style="width: 35%;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">PROFILE1</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">ON</div> <div style="display: flex; border: 1px solid black; margin-bottom: 5px;"> <div style="flex: 1; padding: 2px;">WEEKLY</div> <div style="border-left: 1px solid black; padding: 2px; text-align: center;">▼</div> </div> <div style="display: flex; border: 1px solid black; margin-bottom: 5px;"> <div style="flex: 1; padding: 2px;">MON</div> <div style="border-left: 1px solid black; padding: 2px; text-align: center;">▼</div> </div> <div style="display: flex; border: 1px solid black;"> <div style="flex: 1; padding: 2px;">1</div> <div style="border-left: 1px solid black; padding: 2px; text-align: center;">▼</div> </div> </div> </div>	DESTINATION <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 60%;"> EVENT TYPE </div> <div style="width: 35%;"> <div style="border: 1px solid black; padding: 2px;">4 SELECTED</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">▼</div> </div> </div> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="width: 10%; padding: 2px;">EDIT</th> <th style="padding: 2px;">E-MAIL ADDRESS</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px; text-align: center;"> <div style="display: flex; justify-content: space-around;"> ✎ ✖ </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> + 📧 </div> </td> <td style="padding: 2px;"> tech_support@gmail.com </td> </tr> </tbody> </table>	EDIT	E-MAIL ADDRESS	<div style="display: flex; justify-content: space-around;"> ✎ ✖ </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> + 📧 </div>	tech_support@gmail.com																													
EDIT	E-MAIL ADDRESS																																	
<div style="display: flex; justify-content: space-around;"> ✎ ✖ </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> + 📧 </div>	tech_support@gmail.com																																	
CHANNEL <div style="display: flex; align-items: center; margin-top: 5px;"> <input checked="" type="checkbox"/> ALL </div> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <tr> <td style="width: 25%; padding: 2px;">CH1</td> <td style="width: 25%; padding: 2px;">CH2</td> <td style="width: 25%; padding: 2px;">CH3</td> <td style="width: 25%; padding: 2px;">CH4</td> </tr> <tr> <td style="text-align: center; padding: 2px;"><input checked="" type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input checked="" type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> </tr> <tr> <td style="padding: 2px;">CH5</td> <td style="padding: 2px;">CH6</td> <td style="padding: 2px;">CH7</td> <td style="padding: 2px;">CH8</td> </tr> <tr> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> </tr> <tr> <td style="padding: 2px;">CH9</td> <td style="padding: 2px;">CH10</td> <td style="padding: 2px;">CH11</td> <td style="padding: 2px;">CH12</td> </tr> <tr> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> </tr> <tr> <td style="padding: 2px;">CH13</td> <td style="padding: 2px;">CH14</td> <td style="padding: 2px;">CH15</td> <td style="padding: 2px;">CH16</td> </tr> <tr> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> <td style="text-align: center; padding: 2px;"><input type="checkbox"/></td> </tr> </table>		CH1	CH2	CH3	CH4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	CH5	CH6	CH7	CH8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	CH9	CH10	CH11	CH12	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	CH13	CH14	CH15	CH16	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	→
CH1	CH2	CH3	CH4																															
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>																															
CH5	CH6	CH7	CH8																															
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																															
CH9	CH10	CH11	CH12																															
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																															
CH13	CH14	CH15	CH16																															
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																															
<div style="border: 1px solid black; padding: 2px; display: inline-block;">APPLY</div>																																		

Step1: In **SOURCE**, choose the profile you'd like to save all the settings configured in **SOURCE**.
 Choose how often and when you'd like to receive reports. Finally, make sure this profile is active (**ACTIVE** to **ON**).

EXECUTION PERIOD	Select how often you want to receive reports: MONTHLY , WEEKLY or DAILY .
EXECUTION DAY OF MONTH / EXECUTION DAY OF WEEK	Depending on the option you selected in EXECUTION PERIOD : ■ EXECUTION DAY OF MONTH shows when MONTHLY is selected. Select one date from 1 ~ 31. ■ EXECUTION DAY OF WEEK shows when WEEKLY is selected. Select one day from Monday ~ Sunday.

Step2: In **CHANNEL**, choose the channel(s) you want.

Step3: In **DESTINATION**, choose which event type(s) you want to see (**MANUAL** / **MOTION** / **ALARM** / **SYSTEM** / **TIMER** / **HUMAN DETECTION**).

Step4: Click  to manually add an Email address to receive reports or  to select from the E-mail address list pre-defined in **NETWORK** → **E-MAIL**,  to modify the selected Email address, and  to remove the selected Email address from the recipients list.

Step5: Click **APPLY** to confirm.